ASSEMBLY INSTRUCTIONS SKU: EDT



175 Southbelt Industrial Dr Houston, TX 77047

Email: info@eastwestfurniture.net



Description : EDEN COUNTER HEIGHT ROUND 30" TABLE

Dimension : Ø30"x36".H

Cube Size : 32.3"x32.3"x4.9" NW: 15.4 LBS

(TOP) GW: 19.8 LBS

Cube Size : 31.5"x6.7"x6.7" NW: 8.8 LBS

(PEDESTAL) GW: 11 LBS

EDEN COUNTER HEIGHT ROUND 30" TABLE

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instructions carefully.

Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Please separate, identify, and count all parts and metal hardware. Compare with part list to be sure all parts are present. If hardware is missing or you have difficulty assembling this product, please call for us.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
Α	Тор	1		В	Leg	4	
С	Pedestal	1		D	Cross piece	1	


HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Large flat washer (Φ8.5xΦ19mm)	4		2	Large lock washer (Φ8.5xΦ11mm)	4	
3	Hexagon nut (M8x13mm)	4		4	Wrench (M13mm)	1	
5	Small flat washer (Ф6.5хФ13mm)	4		6	Small lock washer (Ф6.5хФ9mm)	12	
7	Bolt (M6x35mm)	12		8	Allen key (M4)	1	
9	Medium flat washer (Φ6.5xΦ16mm)	8					


STEP 1

Attach legs (B) to the pedestal (C) with washers (1), (2) and nuts (3). Tighten with wrench (4).



STEP 2

Put the cross piece (D) on top of the pedestal, and attach with bolts (7), washers (5), (6). Tighten with Allen key (8).



EDEN COUNTER HEIGHT ROUND 30" TABLE

- 3 -

STEP 3

Carefully place the cross frame (from Step 2) on bottom side of the table top (A), attach with bolts (7), washers (9), (6). Tighten with Allen key (8).

