



ASSEMBLY INSTRUCTION VIDEO SKU: XT60

VIEW ON SMARTPHONE





1. Open Camera app


2. Postion camera to the QR code



3. Click on the pop-up link

VIEW ON COMPUTER






X-Style 36X60 in Dining Table	X-Stv	vle 3	36X60	in D	ining	Table
-------------------------------	-------	-------	-------	------	-------	-------

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:



HARDWARE LIST


When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Bolt (M6x50)	16		2	Lock washer (F 6.5xF 9mm)	12	\bigcirc
3	Flat Washer (F 6.5xF 19mm)	12	\bigcirc	4	Allen key (M4mm)	1	

STEP 1


Attach legs (B) to the Cross bar (C) with Bolts (1). Tighten with the Allen Key (4).

Note: DO NOT tighten any of the bolts, until the table is assembled.



STEP 2

Attach legs (on the Step 1) to the Top (A) with Bolts (1) and washers (2), (3). Tighten with the Allen Key (4). Note: Tighten the all bolts on the Step 1. Then Attach Snap legs (D) to the Legs.



X-Style 36X60 in Dining Table